

b. Fuel Pump Group (fig. 10) (contd).

Ref. No.	Quan. in equip.	Signal Corps stock number	Name of part and description	Function	Mfr.	Kohler part No.
153450	2	Cap, spring.	For large springs.	A	153450
153452	1	Cover, fuel pump side.	For side of pump.	A	153452
153453	1	Rod, fuel pump pull.	A	153453
153454	1	Gasket, fuel pump pull rod.	A	153454
153455	1	Protector.	Lower diaphragm protector.	A	153455
153456	1	Protector.	Upper diaphragm protector.	A	153456

c. Governor Group (fig. 12).

Ref. No.	Quan. in equip.	Signal Corps stock number	Name of part and description	Function	Mfr.	Kohler part No.
	1	3H1921/G65	*Governor assembly.	Controls engine rpm.	K	5680
A-524	1	*Gear, governor (magneto).	Operates magneto drive shaft.	K	A-524
A-536	4	Washer, packing.	For magneto coupling (female).	K	A-536
A-627	1	Nut, magneto drive shaft.	K	A-627
A-628	1	Washer, magneto drive shaft.	Fits on shaft between nut and gear.	K	A-628
A-629	1	Washer, magneto drive shaft.	K	A-629
A-1-630	1	Drive shaft assembly.	Drives magneto and operates governor.	K	A-1-630
A-635	2	Weight.	K	A-635
A-637	1	Pin, governor flyweight hub.	K	A-637
A-638	2	Stud, governor sliding sleeve.	Supports governor fork.	K	A-638
A-639	2	Pin, governor flyweight.	K	A-639
A-640	2	Link pin, governor sliding sleeve.	K	A-640
A-641	1	Sleeve, governor sliding.	Pushes against governor fork to regulate engine rpm.	K	A-641
A-1-642	1	Collar assembly, governor sliding sleeve.	K	A-1-642

c. Governor Group (fig. 12) (contd).

Ref. No.	Quan. in equip.	Signal Corps stock number	Name of part and description	Function	Mfr.	Kohler part No.
A-645	4	Washer, governor link plate.	K	A-645
A-646	2	Spring, governor flyweight.	Actuates flyweights.	K	A-646
A-654	1	*Retainer (lock ring), magneto coupling.	Locks magneto coupling.	K	A-654
A-659	1	3H1921/G29	*Gasket, governor housing.	Seals governor housing.	K	A-659
A-664	8	Link plate, governor.	Links flyweights to sliding collar and sleeve.	K	A-664
A-669	1	*Coupling, magneto (female).	Coupling on drive shaft to operate magneto.	K	A-669
A-671	1	Bearing, drive shaft.	Permits free rotation of governor (magneto) drive shaft.	K	A-671
A-774	1	*Ball joint, governor rod.	Connects ball joint rod to governor operating fork.	K	A-774
A-837	1	Weight, governor fork.	Counterbalances governor fork.	K	A-837
A-851	2	Link pin, governor flywheel hub.	Secures flywheel hub link.	K	A-851
A-861	2	Nut, ball joint rod.	Connects ball joint to rod.	K	A-861
B-936	1	Locknut.	For governor adjusting screw.	K	B-936
D-1301	1	Housing, governor.	Houses governor assembly.	K	D-1301
D-1302	1	Cover, governor housing.	K	D-1302
D-1306	1	*Gasket, governor housing cover.	Seals cover to housing.	K	D-1306
D-1307	1	Plug, governor housing.	K	D-1307
D-1308	1	*Rod, ball joint.	Controls fuel entering carburetor.	K	D-1308
D-1312-1	1	Fork assembly, governor.	Transmits governor action to carburetor.	K	D-1312-1