

Tires

48 1506-A	F	#	Tire-casing-6.00 x 16 (4 ply) Black			38-9-40-1
01A 1506-A	F	#	Casing-tire-6.00 x 16-4 ply-black & white			38-9-40-1
BB 1507-B	F	#	Casing-tire (32 x 6 - 10 ply)			
09A 1507-A	F	#	Casing-tire 6.50 x 16-4 ply-black			40-1
09A 1507-C	F	#	Casing-tire-6.50 x 16-4 ply-black & white			40-1
BB 1509-A	F	#	Casing-tire (6.00 x 20 - 6 ply)			
48 1509-A	F	#	Tire-casing-6.00 x 16 (6 ply) Black			38-9-40-1
BB 1511-A	F	#	Casing-tire (7.00 x 20 - 8 ply)			
48 1605	F	#	Tube-6.00 x 16			38-9-40-1
	F	.50	01A-18309-A Cylinder-spare wheel lock	1		39-40-1

Service Brakes

78 2012	S	3.50	Plate-housing-RE	1	112"	38
81B 2012	I	6.00	Plate-brake housing RE	1	141"-168"	38-9
81T 2012	I	5.50	Plate-brake housing-RE	1	101"-134"-157"-191" front (122" rr.)	38
09B 2012-B	I	13.00	Plate-frt brake housing-RE	1	09B,19B	40-1
78 2013	S	3.50	Plate-housing-LH	1	112"	38
81B 2013	I	6.00	Plate-brake housing-LH	1	141"-168"	38-9
81T 2013	I	5.50	Plate-brake housing-LH	1	101"-134"-157"-191" Front (122" rr.)	38
91A 2013	S	1.90	Plate-front	2	112"-116"-114"-118"-122"	39-40-1
91T 2013	I	3.40	Plate-front brake	2	101"-134"-157"-191"-158"-194"	39-40-1
09B 2013-B	I	13.00	Plate-front brake housing-LH	1	09B,19B	40-1
	F	.05	78-2249 Bolt-front housing plate	8	112"-116"-114"-118"-122"	38-9-40-1
	F	.06	68-2248 Bolt-rear housing plate-long	4	112"-116"-114"-118"	38-9-40-1
	F	.05	68-2249 Bolt-rear housing plate-short	4	112"-116"-114"-118"	38-9-40-1
			351059-S7 Nut-front housing plate	8	112"-116"-114"-118"-122"	38-9-40-1
			34032-S4 Nut-rear housing plate	4	112"-116"-114"-118"	38-9-40-1
			34032-S4 Nut-rr rad rod & brake hag pl.	4	112"-114"-116"-118"	38-9-40-1
91A 2018	F	1.50	Shoe & lining-forward-moulded woven	4	112"-116"(122" front 1939)	39-40
01A 2018	F	1.45	Shoe & lining-forward-woven	4	112"-116"-114"-118"	40-1
81T 2018	F	3.35	Shoe & lining forward	4	101"-134"-157"-191" Frt & rr.(122"rr.)	38
			22223-S Bolt-frt.,brake plate to spdl.	8	101"-134"-158"-194"	41