

CHASSIS PARTS AND PRICE LIST

PART NUMBER	CASE	LIST PRICE	PART NAME	NO. REQ'D	MODEL	YEAR 19-
91T 2074	F	.30	Connector-brake line-rear-LHD	1	101"-134"-157"-191"	39
92Y 2074	F	.30	Connector-brake line-rear	1	122"	39
99A 2074	F	.20	Tee-brake line	1	116"-114"-118"	39-40-1
01T 2074-A	F	.20	Connector-rear brake line	1	101"-122"-134"-158"-194"	40-1
09B 2074	I	.20	Tee-brake line	1	09B,19B	40-1
			390839-S Plug-rear axle brake line pipe tee	1	19B	41
			20388-87 Bolt-brake tube connector to rear axle housing	1	101"-122"-134"-158"-194"	41
91A 2075	F	.20	Connector-front line	1	112"-116"-114"-118"	39-40-1
91A 2076	F	.20	Fitting-master cyl.outlet-Use with 91A-2265-B	1	112"	39-40
91T 2076	F	.20	Fitting-master cyl.outlet	1	122"-134"-157"-158"-194"	39-40-1
99A 2076	F	.20	Fitting-master cyl.outlet-Use with 91A-2265-A	1	116"-112"-114"-118"	39-40-1
91W 2076	F	.25	Fitting-master cyl.outlet	1	101"	39
91A 2077	F	.15	Bolt-master cyl.outlet fitting	1	112"-116"-114"-118"-101"-122"-134"- 157"-158"-191"-194"	39-40-1
91A 2078-A	F	.75	Hose-rear assy	1	112"-116"-114"-118"	39-40-1
91T 2078-A	F	.90	Hose-rear brake	1	101"-122"-134"-157"-191"	39
01T 2078	F	1.10	Hose-rear brake	1	101"-122"-134"-158"-194"	40-1
99A 2079-A	F	1.00	Hose-front brake	2	112"-116"-114"-118"-101"-122"-134"- 157"-191"-194"	39-40-1
			20359-S2 Bolt-rear brake hose brkt.to frame	1	101"-122"-134"-158"-194"	41
91A 2080	S	.10	Connector-front cyl.inlet-used with 91A2079-A	2	112"	39-40
91T 2080	F	.10	Connection-front cyl.inlet	2	101"-134"-157"-158"-191"-194"	39-40-1
91T 2081	M	.01	Clip-pipe to side member	5or6	101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2082	N	.02	Bracket-front hose	2	112"-116"-114"-118"	39-40-1
91T 2082	F	.20	Bracket-front brake hose	2	101"-134"-157"-158"-191"-194"	39-40-1
01Y 2082	I	.10	Bracket-front brake hose	2	122"	39-40-1
70 2084-B	I	.55	Lever-front brake optg.shaft-3/8" pinhole	2	141"-168"	38-9
78 2088-B	M	.45	Lever-operating RH	2	112"	38
81B 2088	I	1.35	Lever-brake operating-RH	1	141"-168"	38-9
81T 2088	I	1.20	Lever-operating-RH	1	101"-134"-157"-191" frt & rear (122" Rear)	38
78 2089-B	M	.45	Lever-operating LH	2	112"	38
81B 2089	I	1.35	Lever-brake operating-LH	1	141"-168"	38-9
81T 2089	I	1.20	Lever-operating-LH	1	101"-134"-157"-191" frt & rear (122" Rear)	38
11A 2091	F	.04	Washer-hand brake equalizer clevis	1	11A,19A	41
70 2098-A	I	.45	Support-front brake cable & conduit	2	141"	38-9
			34031-S Nut-rear brake hsg.plate bolt	12	101"-122"-134"-141"-148-1/2"-157" 158"-168"-191"-194"	38-9-40-1
			72016-S Cotter-rear brake hsg.plate bolt	12	101"-122"-134"-141"-148-1/2"-157"- 158"-168"-191"-194"	38-9-40-1
70 2098-B	I	*5.50	Support-front brake cable & conduit	2	168"	38-9
70 2099	I	.95	Bracket-front brake hsg.pl.conduit supt.RH	1	141"-168"	38-9
70 2100	I	.95	Bracket-front brake hsg.plate conduit supt.LH	1	141"-168"	38-9
78 2102	F	.15	Clamp-plate conduit	4	112"(122" front 1938-9-40-41)	38
81T 2102	S	.20	Clamp-brake plate conduit	4	(141"-168"-1938-39)-(101"-134"-157"- 191" frt & rear-122" rear-1938)	
91A 2103	S	.50	Lever-emergency RH	1	112"-116"-114"-118"-122" 3/4 ton	39-40-1
92Y 2103	I	.65	Lever-emergency brake-RH	1	(122" 1 ton)	39-40-1
91A 2104	S	.50	Lever-emergency LH	1	112"-116"-114"-118"-122" 3/4 ton	39-40-1
92Y 2104	I	.65	Lever-emergency brake-LH	1	(122" 1 ton)	39-40-1
91A 2105	S	.02	Pin-emergency lever-rear	2	112"-116"-114"-118"-122" 3/4 ton	39-40-1
92Y 2105	S	.03	Pin-rear brake emergency link	2	(122" 1 ton)	39-40-1
78 2106	M	.10	Stud-operating lever	4	112"	38
91A 2106	F	.02	Retainer-emergency lever pin	4	112"-116"-114"-118"-122"	39-40-1
91A 2107	S	.02	Pin-emergency lever	2	112"-116"-114"-118"-122" 3/4 ton	39-40-1