

CHASSIS PARTS AND PRICE LIST

PART NUMBER	CLASS	LIST PRICE	PART NAME	NO. REQ'D	MODEL	YEAR 19-
92Y 2107	S	.03	Pin-rear brake emergency lever	2	(122" 1 ton)	39-40-1
78 2108	F	.40	Stem-adjusting & spring	4	112"	38
81T 2108	S	.25	Stem-adjusting & spring	4	(141"-168" 1938-39)(101"-134"-157"-191" Frt & rear-122" rear-1938)	
91A 2108	S	.15	Link-emergency RH	1	112"-116"-114"-118"-122" 3/4 ton	39-40-1
92Y 2108	I	.20	Link-rear emergency brake-RH	1	122" 1 ton	39-40-1
91A 2109	S	.15	Link-emergency LH	1	112"-116"-114"-118"-122" 3/4 ton	39-40-1
92Y 2109	I	.20	Link-rear emergency brake-LH	1	122" 1 ton	39-40-1
78 2112-B	M	.03	Washer-operating pin	4	112"	38
81T 2112	S	.07	Washer-anchor pin	4	(141"-168" 1938-39)(101"-134"-157"-191" Frt & rear-122" rear-1938)	
91A 2113	F	.01	Plate-emergency cable spring	2	112"-116"-114"-118"(122" 1939)	39-40-1
91A 2119	F	.12	Equalizer-emergency cable	1	112"-116"-114"-118"(122" 1939)	39-40-1
91A 2121	F	.20	Clevis-emergency brake equalizer	1	112"-116"-114"-118"(122" 1939)	39-40-1
09B 2124	I	.15	Washer-brake slack adj retaining-inner		09B,19B	40-1
91A 2125	M	.01	Spring-shoe retainer		112"-116"-114"-118"(122" 1 ton front) (122" 3/4 ton front & rear)	39-40-1
92Y 2125	S	.02	Spring-shoe retainer	4 or 8	101"-134"-157"-158"-191"-194" Frt & Rr (122" 1 ton rear)	39-40-1
09B 2127	B	.05	Retainer-anchor pin washer	16	09B,19B	40-1
			352954-S Pin-brake master cyl.operating lever shaft	1	00E	40-1
91D 2131	F	.15	Fitting-rear wheel cylinder	2	(122" 3/4 ton)	39-40-1
91A 2133	F	.05	Nut-brake pipe-used with 91A-2269	2	All models	39-40-1
91A 2140	F	5.00	Cylinder-master-complete	1	112"-116"-114"-118"	39-40-1
91T 2140	F	6.00	Cylinder-master-complete	1	101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2141	F	2.50	Cylinder-master & plug	1	112"-116"-114"-118"	39-40-1
91T 2141	F	3.25	Cylinder-master & plug	1	101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2143-A	F	.25	Link-master cyl.	1	112"-116"-114"-118"	39-40-1
91T 2143-A	F	.45	Link-master cyl.	1	101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2149	F	.01	Gasket-front line conn.	2	112"-116"-114"-118"-101"122"-134"-157"-158"-191"-194"	39-40-1
91A 2149	F	.01	Gasket-rear wheel cyl. fitting	2	122" 3/4 ton	40-1
91A 2150	F	.10	Bolt-Front line conn.	1	112"-116"-114"-118"	39-40-1
91A 2151	F	.01	Gasket-master cyl.outlet-large	1	112"-116"-114"-118"-101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2152	F	.01	Gasket-master cyl.outlet small	1	112"-116"-114"-118"-101"-122"-1 ton 134"-157"-158"-191"-194"	39-40-1
91A 2152	F	.01	Gasket-rear brake cyl. inlet connection	4	101"-122"-1 ton-134"-157"-158"-191"-194"	39-40-1
91T 2154	F	.01	Gasket-frt brake cyl. inlet	2	101"-134"-157"-158"-191"-194"	39-40-1
91A 2162-A	F	.35	Cap-master cyl.filler	1	112"-116"-114"-118"-101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2167	F	.03	Gasket-master cyl.filler cap	1	112"-116"-114"-118"-101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2169	F	.70	Piston-master cyl.	1	112"-116"-114"-118"	39-40-1
91T 2169	F	.80	Piston-master cylinder	1	101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2173-A	F	.15	Cup-master cyl.-primary 1-1/16"	1	112"-116"-114"-118"	39-40-1
91T 2173-A	F	.20	Cup-master cyl.-primary - 1-1/4"	1	101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2174	F	.03	Ring-master cyl.piston snap	1	112"-116"-114"-118"	39-40-1
91T 2174	F	.03	Ring-master cyl.piston snap	1	101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2177	F	.05	Spring-master cyl.piston return	1	112"-116"-114"-118"	39-40-1
91T 2177	F	.12	Spring-master cyl.piston return	1	101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2178	F	.45	Valve-master cyl.	1	112"-116"-114"-118"	39-40-1
91T 2178	F	.50	Valve-master cyl.	1	101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2180	F	.15	Boot-master cyl.	1	112"-116"-114"-118"	39-40-1
91T 2180	F	.25	Boot-master cylinder	1	101"-122"-134"-157"-158"-191"-194"	39-40-1
91A 2185	F	.05	Retainer-master cyl.return spring	1	112"-116"-114"-118"	39-40-1
91T 2185	F	.05	Retainer-master cyl.return spring	1	101"-122"-134"-157"-158"-191"-194"	39-40-1