

CHASSIS PARTS AND PRICE LIST

PART NUMBER	CLASS	LIST PRICE	PART NAME	NO. REQ'D	MODEL	YEAR 19-
70 3180	I	.07	Pin-spindle nut	2	141"-168"	38-9
09B 3180	B	.07	Pin-spindle lock nut	2	09B,19B	40-1
09B 3272	I	.30	Ring-spindle conn.rod spring clamp	2	09B,19B	40-1
70 3276	I	.60	Nut-spindle lock-outer	2	141"-168"	38-9
09B 3276	B	.55	Nut-spindle lock-outer	2	09B,19B	40-1
70 3277	B	.15	Spring-spindle bolt oil seal retainer	2	141"-168"	38-9
09B 3277	B	.05	Spring-spindle pin oil seal retainer	2	09B,19B	40-1
70 3278	B	.75	Plug-spindle connecting rod end	2	141"-168"	38-9
09B 3278	B	.15	Plug-spindle conn.rod end	2	09B,19B	40-1
51 3281-A	F	1.80	Tube-spindle connecting rod	1	134"-157"-158"-191"-194" except COE	38-9-40-1
70 3281	I	2.20	Tube-spindle connecting rod	1	141"-168"	38-9
81W 3281	I	2.75	Tube-spindle connecting rod	1	COE	38-9-40-1
70 3282	B	.60	Seat-spindle connecting rod ball	4	141"-168"	38-9
09B 3282-B	B	.25	Seat-spindle conn.rod spring	2	09B,19B	40-1
78 3283	F	.95	Tube-spindle conn.rod	1	112"-116"-114"-118"-122"	38-9-40-1
09B 3283	I	9.00	Tube-spindle conn.rod	1	09B,19B	40-1
81W 3284	I	.30	Stud-spindle conn.rod ball	1	(COE-1938-39)(101"-134"-158"-194"-1940-41)	38-9-40-1
09B 3284	I	3.00	Stud-spindle conn.rod ball end	2	09B,19B	40-1
70 3285	B	5.25	End-spindle connecting rod-RH	1	141"-168"	38-9
09B 3285	B	7.00	End-spindle conn.rod-RH	1	09B,19B	40-1
70 3286	B	5.25	End-spindle connecting rod-LH	1	141"-168"	38-9
09B 3286	B	6.75	End-spindle conn.rod-LH	1	09B,19B	40-1
48 3287	F	.05	Clamp-spindle conn.rod end	4	112"-116"-114"-118"-122"	38-9-40-1
			22228-S2 Bolt-spindle conn.rod clamp	2	112"-116"-114"-118"-122"	38-9-40-1
			34029-S2 Nut-spindle conn.rod clamp bolt	2	112"-116"-114"-118"-122"	38-9-40-1
			72008-S Cotter-spindle conn.rod end clamp bolt	2	112"-116"-114"-118"-122"	38-9-40-1
B 3288	F	.05X .01	Retainer-spindle bolt dust washer	2	112",114"-116"-118"-122"	38-9-40-1
70 3288	B	.05	Retainer-spindle pin oil seal felt	2	141"-168"	38-9
81T 3288	F	.04	Retainer-spindle bolt felt	2	101"-134"-157"-158"-191"-194"	38-9-40-1
09B 3288	B	.05	Retainer-spindle pin oil seal	2	09B,19B	40-1
78 3289-B	F	1.10	End-spindle conn.rod-RH (In carton)	1	112"-116"-114"-118"-122"	38-9-40-1
01T 3289	F	1.20	End-spindle conn.rod-RH	1	101"-134"-157"-158"-191"-194"	38-9-40-1
11A 3289-B	F	.95	End-spindle conn.rod - RH	1		
78 3290-B	F	1.10	End-spindle conn.rod LH (In carton)	1	112"-116"-114"-118"-122"	38-9-40-1
			33983-S Nut-spindle conn.rod ball stud	2	112"-116"-114"-118"-122"	38-9-40-1
			72026-S Cotter-spindle conn.rod ball stud	2	112"-116"-114"-118"	38-9-40-1
			72026-S Cotter-drag link ball stud-strg. arm end	1	112"-116"-114"-118"	38-9-40-1
78 3290-B	F	1.10	End-drag link adjustable	1	112"-116"-114"-118"	38-9-40-1
			353043-S7 Lubricator fitting-spindle conn rod end	2	112"-116"-114"-118"	38-9-40-1
11A 3290-B	F	.95	End-spindle conn. rod LH	1		
01T 3290	F	1.20	End-spindle conn.rod LH	1	101"-134"-157"-158"-191"-194"	38-9-40-1
			72035-S Cotter-conn.rod ball stud	2	101"-134"-141"-157"-158"-168"-191"-194" (122"-1938)	38-9-40-1
			34020-S2 Nut-spindle conn.rod	2	101"-134"-141"-157"-158"-168"-191"-194" (122"-1938)	38-9-40-1
			353031-S7 Lubricator fitting 1/4-27	2	101"-134"-157"-158"-191"-194"	38-9-40-1
			353043-S7 Lubricator fitting-spind.conn. rod end	2	122"	38-9-40-1
			72009-S Cotter-spin.conn.rod clp.bolt	2	101"-134"-141"-157"-158"-168"-191"-194"	38-9-40-1
			34020-S2 Nut-spin.conn.rod slotted 9/16"-18	2	101"-134"-157"-158"-191"-194"	38-9-40-1
			353035-AS7 Lubricator fitting-front spindle rod	4	101"-134"-141"-157"-158"-168"-191"-194"	38-9-40-1