



**CHASSIS PARTS AND PRICE LIST**

PART NUMBER	QTY	LIST PRICE	PART NAME	NO. REQ'D	MODEL	YEAR 19--
99A 3440	F	.55	Cap-front radius rod ball	1	116"	39-40
11A 3440	F	.20	Cap-front radius rod ball	1	114"-118"	41
			20351-S2 Bolt-frt.radius rod ball cap	2	19A	41
			brkt-frt to frame			
99A 3441-B	F	.10	Bolt-front radius rod ball cap	2	116"	39-40
81C 3442	S	.60	Spacer-radius rod ball-used with 4 speed trans	1	112" Comm.	39-40-1
B 3446	F	.10	Bushing-front radius rod rubber	1	112"	38-9-40-1
			72035-S Cotter-front radius rod bolt	2	112"-116" -114"-118"	38-9-40-1
B 3446	F	.10	Bushing-front radius rod rubber	1	122"-134"-157"-191" except COE	38-9
			353037-S7 Fitting-drag link lubricator	2	09B,19B	40-1
99A 3446	F	.20	Bushing-front radius rod rubber	1	116"	39-40
11A 3446	F	.20	Bushing-front radius rod rubber	1	114"-118"	41
			22481-S2 Bolt-frt rad.rod ball cap to brkt	2	19A	41
			22623-S2 Bolt-frt rad.rod ball cap to fr.	2	11A	41

**Steering Gear**

70 3503-B	I	*26.75	Steering gear-less wheel & steering arm	1	141"-168"	38-9
81A 3503	S	15.00	Gear-strg.less wheel & arm-Zephyr Beige LHD	1	112" Pass	38-9
81C 3503	S	15.00	Gear-strg.less wheel & arm LHD	1	Commercial	38-9
81T 3503	B	17.75	Gear-steering less wheel & arm LHD	1	134"-157"-191" except COE	38-9
81W 3503	S	*19.75	Gear-steering-LHD	1	COE	38-9
			22495-S2 Bolt-steer.gear to frame	2or3	101"-134"-157"-158"-191"-194"	38-9-40-1
			34031-S Nut	3	101"-134"-157"-158"-191"-194"	38-9-40-1
			72016-S Cotter	3	101"-134"-157"-158"-191"-194"	38-9-40-1
82Y 3503	S	15.00	Gear-steering-less wheel & arm LHD	1	122"	38-9
99A 3503	S	12.25	Gear-strg.less wheel & arm LHD	1	116"	39
01A 3503-A	S	22.00	Gear-strg.less wheel & arm LHD	1	112" Std.Pass	40
01A 3503-B	S	22.25	Gear-strg.less wheel & arm-LHD	1	112" DeLuxe Pass	40
01C 3503-A	F	15.50	Gear-strg.less wheel & arm LHD	1	Comm. except 11C78,11C78	40-1
01T 3503	F	17.00	Gear-strg.-less wheel & arm-LHD	1	134"-158"-194" except COE	40-1
01W 3503	I	20.75	Gear-strg.-less wheel & arm-LHD	1	COE	40-1
01Y 3503	F	15.50	Gear-strg.less wheel & arm-LHD	1	122"	40-1
09A 3503	F	24.75	Gear-strg.less wheel & arm LHD	1	116"	40
			20391-S4 Bolt-brkt.to frame	4	116"-118"	39-40-1
			22494-S Bolt-housing to frame	3	112"-116"-114"-118"-122"	38-9-40-1
			34030-S2 Nut-strg.gear to frame brkt.	2	112"-116"-114"-118"-122"	38-9-40-1
			33800-S2 Nut-strg.gear to frame brkt.top	1	112"-116"-114"-118"-122"	38-9-40-1
			34807-S2 Lockwasher-top rear hole	1	112"-116"-114"-118"-122"	38-9-40-1
			rear			
			34747-S2 Washer-hsg. to frame	3	112"-116"-114"-118"-122"	38-9-40-1
			72009-S Cotter-steering gear to frame bolt	2	112"-116"-114"-118"-122"	38-9-40-1
	F	.01	B-6033 Washer-strg.gear brkt.to frame	2	09A,19A	40-1
09B 3503	I	*28.00	Gear-strg.less wheel & arm	1	09B,19B	40-1
11A 3503-D	F	21.50	Gear-steering-less wheel & arm-LHD	1	11A	41
11C 3503-B	F	21.50	Gear-steering- less wheel & arm-LHD	1	11C78,11C78	41
19A 3503-A	F	22.50	Gear-steering-less wheel & arm-LHD-used with	1	19A	41
			starter switch push button in lock body			
19A 3503-B	F	21.50	Gear-steering-less wheel & arm-LHD-used with	1	19A	41
			starter switch push button in instr.panel			