

## INDEX TO GROUP NUMBERS

SERIES	GROUP	SERIES	GROUP
1000-1250	Wheels, Hubs & Rims	9904-9974	Carburetor
1351-1499	Spare Wheel Carrier	10000-10449	Generator
1500-1723	Tires	10500-10649	Cutout
2006-2449	Brakes (Service)	10650-10848	Battery
2450-2553	Brake (Controls)	10849-10899	Instrument Cluster & Ammeter
2594-2872	Brakes (Emergency)	11000-11516	Starter Motor
3000-3451	Front Axle	11648-11688	Lighting Switch
3500-3743	Steering Gear	12000-12327	Ignition Coil, Distributor, Condenser
4000-4799	Rear Axle	12405-12425	Spark Plug
4800-4999	Coupling Shaft	13002-13399	Head, Fender & Cowl Lamps
5000-5149	Frame & Brackets	13400-13799	Lighting Stop, Tail & Dome Lights
5150-5224	Battery Brackets & Parts	13800-13899	Horn
5225-5299	Muffler & Exhaust Pipe	14054-14621	Wiring
5300-5515	Front Springs	16000-16149	Front Fender
5550-5818	Rear Springs	16150-16449	Rear Fender
6000-6928	Engine	16450-16524	Running Board
7000-7449	Transmission	16525-16599	Running Board Shields
7500-7646	Clutch	16600-16799	Hood
8000-8499	Radiator	17003-17088	Tools
8500-8599	Water Pump Assy	17250-17499	Speedometer
8600-8633	Fan	17500-17674	Windshield Wiper
9002-9269	Fuel Tank	17750-17999	Bumpers
9270-9420	Fuel Pump	18000-18199	Shock Absorber
9421-9499	Manifolds, Clamps, etc.	18400-18600	Miscellaneous Accessories
9500-9699	Carburetor	18650-18675	Oil Filter
9700-9828	Acc. Spark & Throttle Control Rods		